



1	<ul style="list-style-type: none"> ● RAIDISSEUR BASE BATTERIE À ROULETTES v3 S00-22777-20 (u. 1) 	
2	<ul style="list-style-type: none"> ● DOUILLE BASE BATTERIE À ROULETTES S01 S01-22776-00 (u. 2) 	
3	<ul style="list-style-type: none"> ● FIXATION CYLINDRIQUE BP S01 v2 S00-22773-30 (u. 2) 	
4	<ul style="list-style-type: none"> ● ÉCROU AUTOBLOQUANT 08319-08001 (u. 2) 	
5	<ul style="list-style-type: none"> ● DOUILLE AUTOLUBRIFIANTE IGLIDUR S01-22722-00 (u. 2) 	
6	<ul style="list-style-type: none"> ● DOUILLE ARTICULATION 2S00 S00-22746-00 (u. 2) 	
7	<ul style="list-style-type: none"> ● VIS M8x35 TORX 07190-08035 (u. 2) 	
9	<ul style="list-style-type: none"> ● VIS VERROU BP S00-45051-00 (u. 1) 	
dix	<ul style="list-style-type: none"> ● Sous-ensemble roue S01-22720-10 (u. 1) 	OBSOLÈTE
11	<ul style="list-style-type: none"> ● VIS M10x20 8.8 (FIXATION-TORX) 07120-10020F (u. 1) 	
12	<ul style="list-style-type: none"> ● ROUE BP AMOVIBLE GRIS S01-22350-10 (u. 2) 	
13	<ul style="list-style-type: none"> ● VIS M4x10 8,8 (FIXATION) 02132-04010F (u. 4) 	
14	<ul style="list-style-type: none"> ● Tôle renfort base batterie à roulettes S01-22778-00 (u. 2) 	